

Polaroid



8" Wi-Fi Digital Picture Frame

PDWX-800CD

Quick Start Guide



Attach stand



Plug in



Frame powers on automatically when first plugged in


When the frame powers on the Polaroid logo will flash twice on the screen while system initializes.



Follow the prompts on the start screen



1 Download the **Polaroid Wi-Fi Photo Frame 3.0** app on an Android/iOS smartphone or iPad



2 Connect frame to a Wi-Fi network
Wi-Fi router with a 2.4GHz internet connection required



3 Link frame to Android/iOS smartphone or iPad
Select Link Frames in the app and enter the secure 8-digit Photo Frame Code or scan QR code to quickly link the Wi-Fi photo frame.



PLEASE do NOT return your product to the store.

No devuelva su producto a la tienda.

Do not discard. Keep this document in a safe place for future reference.

No desechar. Guarde este documento en un lugar seguro para consultarlo en el futuro.

Polaroid and Polaroid Color Spectrum are trademarks of PLRIP Holdings, LLC, used under license. PLRIP Holdings, LLC does not manufacture this product or provide any Manufacturer's Warranty or support.
© 2020 All Rights Reserved

NEED HELP?

¿NECESITA AYUDA?



If you still have questions, call our help line
Llame el Servicio al Cliente a

1-855-544-4841

Or visit
o visite

www.polaroid.com

Polaroid y Polaroid Color Spectrum son marcas comerciales de PLRIP Holdings, LLC, usadas bajo licencia. PLRIP Holdings, LLC no fabrican este producto ni proporcionan ninguna garantía y servicio del fabricante.
© 2020 Reservados todos los derechos