



Wi-Fi)))

10" TOUCHSCREEN DIGITAL PICTURE FRAME

Black Woodgrain Frame

PDWV-1050B

QUICK START GUIDE



Attach stand



Plug in




Frame powers on automatically when first plugged in

When the frame powers on the Polaroid logo will flash twice on the screen while system initializes.




Follow the prompts on the start screen



1 Download the Polaroid Wi-Fi Photo Frame 2.0 App on an Android/iOS smart phone or iPad



2 Connect frame to a Wi-Fi network



3 Link frame to an Android/iOS smart phone or iPad



**PLEASE DO NOT
return your product
to the store.**

Do not discard. Keep this document in a safe place for future reference.

NEED HELP?




If you still have questions, call our help line

1-855-544-4841

Or visit

www.polaroid.com



Instantly recognizable, instantly reassuring. The Polaroid Classic Border and Polaroid Color Spectrum Logos let you know you've purchased a product that exemplifies the best qualities of our brand and that contribute to our rich heritage of quality and innovation.

Polaroid, Polaroid & Pixel, Polaroid Classic Border Logo and Polaroid Color Spectrum are trademarks of PLR IP Holdings, LLC, used under license. PLR IP Holdings, LLC does not manufacture this product or provide any Manufacturer's Warranty or support.
© 2019 All Rights Reserved