

Polaroid



10" Wi-Fi Digital Picture Frame

PDWX-1050BB


Quick Start Guide



Attach stand



Plug in




Frame powers on automatically when first plugged in

When the frame powers on the Polaroid logo will flash twice on the screen while system initializes.



Download the **Polaroid Wi-Fi Photo Frame 3.0** app on an Android/iOS smartphone or iPad



Connect frame to a Wi-Fi network
Wi-Fi router with a 2.4GHz internet connection required



Link frame to Android/iOS smartphone or iPad
Select Link Frames in the app and enter the secure 8-digit Photo Frame Code or scan QR code on the digital frame screen to quickly link the Wi-Fi photo frame.



STOP

PLEASE do NOT return your product to the store.

No devuelva su producto a la tienda.

Do not discard. Keep this document in a safe place for future reference.

No desechar. Guarde este documento en un lugar seguro para consultarlo en el futuro.

This product is manufactured, distributed and sold by PA Brands. The POLAROID word and logos are protected trademarks of Polaroid, used under license. Polaroid does not manufacture this product, nor provide any product warranties or support.
© 2023 All Rights Reserved

NEED HELP?

¿NECESITA AYUDA?



If you still have questions, call our help line

Llame el Servicio al Cliente a

1-855-544-4841

Or visit
o visite

www.mydigitalframe.com

Este producto es fabricado, distribuido y vendido por PA Brands. La palabra y los logotipos POLAROID son marcas comerciales protegidas de Polaroid, utilizadas bajo licencia. Polaroid no fabrica este producto, ni proporciona ninguna garantía o soporte del producto.
© 2023 Reservados todos los derechos